



Please read all instructions prior to installation and keep for future reference!

T 224.333.6033 www.opticarts.com


- 1. Product should be installed by a qualified electrician.
- 2. Prior to installation ensure power is off at fuse box to prevent electrical shock.

Page 1 of 2






If required for installation cut down ALE aluminum extrusion to desired length with hacksaw or miter saw that has an appropriate blade for cutting aluminum. Always wear safety goggles when cutting.





fits completely inside the extrusion and the solder pads do not

ouch the metal end caps to avoid shorting of circuit.



Drill location for mounting holes at appropriate intervals, after locating stud supports in the wall. Ensure appropriate drill bit is used to drill in the aluminum extrusion.





Remove paper-backing from adhesive tape on the back of the 1 Line LED strip before installing onto the ALE extrusion. Once the Line LED strip is in place, snap on the diffuser lens. Remove the protective film from the lens.

ALE Channel - Installation Instructions





Please read all instructions prior to installation and keep for future reference!


T 224.333.6033 www.opticarts.com

- 1. Product should be installed by a qualified electrician.
- 2. Prior to installation ensure power is off at fuse box to prevent electrical shock.

Page 2 of 2







Ensure power is off to power supply!

Then proceed to connect Line LED wires from ALE extrusion to power supply. Connection can be established with lead wires or quick-connect powerfeed. For more information please refer to power supply and Line LED wiring instructions.